
Name: Waqar Ahmed

Roll No: 20P-0750


Task No: 05

### **Exp1: DNS server configuration in Packet Tracer.**





#### Exp:2

#### **Step1:** Create This Topology.



**Step2:** Assign Ip address to F0/0 and F0/1 of router.





**Step3:** Open the CLI tab in the **Router0** and go the configuration mode and execute the following commands.

To Go To the configuration mode

=> configure terminal

```
Router#
Router#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#ip dhcp pool P1
Router(dhcp-config)#network 192.168.1.0 255.255.255.0
Router(dhcp-config)#default-router 192.168.1.2
Router(dhcp-config)#ip dhcp pool P2
Router(dhcp-config)#network 192.168.2.0 255.255.255.0
Router(dhcp-config)#default-router 192.168.2.2
Router(dhcp-config)#
```


#### Step4: Apply follows setting on DHCP IP configurations.




# **Step5:** Open the services tab and enable DHCP Services and Add Pool P1 and Pool P2 with respective Ip Address.




Step 6: Apply follows setting on DNS Ip configuration.




**Step7:** Enable DNS Services of DNS and add two resources records. Remember To On the DNS Service.




Step8: Apply following IP configuration on the Web Server.



**Step9:** Go to Services Tab and then Enable Http and Https in Web Server.



#### Step10: Edit the index.html file



**Step11:** Now go to every PC and on their IP configuration tabs, enable DHCP. Every PC should be able to obtain an IP address, default gateway and DNS server.

## Click PC17->Desktop->IP configuration. Then enable DHCP:

